

		FHSS Receiver		S-FHSS Receiver						T-FHSS	T-FHSS Air
		R603GF (3CH)	R2004GF (4CH)	R203GF (3CH)	R204GF-E (4CH)	R2104GF (4CH)	R2006GS (6CH)	R2106GF (6CH)	R2008SB (8CH)	R304SB / R304SB-E (4CH)	R3006SB (6CH) R3008SB (8CH)
T4YF	FHSS	OK (3ch)	OK	OK (3ch)	OK	OK	OK	OK	OK	—	—
T6J	S-FHSS	—	—	OK (3ch)	OK (4ch)	OK (4ch)	OK	OK	OK	—	—
	FHSS	OK (3ch)	OK (4ch)	OK (3ch)	OK (4ch)	OK (4ch)	OK	OK	OK	—	—
T8J	S-FHSS	—	—	OK (3ch)	OK (4ch)	OK (4ch)	OK	OK	OK	—	—
	FHSS	OK (3ch)	OK (4ch)	OK (3ch)	OK (4ch)	OK (4ch)	OK (6ch)	OK (6ch)	OK	—	—
T6K	T-FHSS	—	—	—	—	—	—	—	—	—	OK
	S-FHSS	—	—	OK (3ch)	OK (4ch)	OK (4ch)	OK	OK	OK	—	—
T10J	T-FHSS	—	—	—	—	—	—	—	—	—	OK
	S-FHSS	—	—	OK (3ch)	OK (4ch)	OK (4ch)	OK	OK	OK	—	—